

# Operation manul of combination machine

## Sliding table support installation



**Tips:** Please carefully read the operation after installation, pay attention to wear protective gloves.

- 1- Loosen the two nuts and put the spindle out.



- 2- Assemble the swinging arm and Put the spindle in swinging arm.






3- Fix the universal foot on the spindle





4- Lock the two screw and nuts.



5- Assemble the sliding table support





- 6- Put the 40\*40 Aluminum square rail on the sliding table and table support.adjust it.





7- Assemble the guiding ruler

